

Zinc Anode Replacement Instructions

PART # 104R-KIT

1. Turn off the pump.
2. Disconnect the bonding wire. (fig 1)
3. Unscrew the cap and remove the anode.
4. Replace the 'O' ring on the housing. (fig 2)
(Be sure to lubricate the new 'O' ring)
5. Install the new anode kit.
6. Connect the bonding wire.

MADE IN USA



(Fig 1)



(Fig 2)



NOTE:

The zinc anode will gradually sacrifice itself (erode). A scaly residue will occur and should be removed with sandpaper about every six months.

The anode should be replaced when it is half its original size. This takes approximately 3 years.

If you have any questions, please call Herb at 805-644-2333.



POOL TOOL COMPANY®
pooltool.com

Phone: 805-644-2333

Address:

4848 Colt st. #10
Ventura CA 93003