

POOL & SPA WATER TESTS

Guide book (#2004B) amplifies these instructions and should be read to use this product properly.

1. Read precautions on all labels
2. Keep test kit out of reach of children.
3. Store test kit in cool, dark place.
4. Replace reagents once each year.
5. Do not dispose of solutions in pool or spa.
6. Rinse tubes before and after each test.
7. Obtain samples 18" (45 cm) below water surface.
8. Hold bottle vertically when dispensing.

Chlorine (Free, Combined, Total) Test

1. Rinse and fill small comparator tube to 9 mL mark with water to be tested.
2. Add 5 drops R-0001 and 5 drops R-0002. Cap and invert to mix.
3. Match color with color standard.* Record as parts per million (ppm) free chlorine (FC).
4. Add 5 drops R-0003. Cap and invert to mix.
5. Match color immediately. Record as ppm total chlorine (TC).
6. Subtract FC from TC. Record as ppm combined chlorine (CC).
Formula: $TC - FC = CC$.

Total Bromine Test

1. Rinse and fill small comparator tube to 9 mL mark with water to be tested.
2. Add 5 drops R-0001 and 5 drops R-0002. Cap and invert to mix.
3. Match color with color standard.* Record as parts per million (ppm) total bromine.

* If color is off-scale: Repeat test using 4.5 mL sample diluted to 9 mL mark with tap water. Multiply reading by 2 to obtain approximate sanitizer level. If color is still off-scale: Repeat test using 1.8 mL sample diluted to 9 mL mark with tap water. Multiply reading by 5 to obtain approximate sanitizer level.

pH Test

1. Rinse and fill large comparator tube to 44 mL mark with water to be tested.
2. Add 5 drops R-0004. Cap and invert to mix.
3. Match color with color standard. Record as pH units and save sample if pH needs adjustment. If sample color is between two values, pH is average of the two. To LOWER pH: See acid demand test. To RAISE pH: See base demand test.

Acid Demand Test

1. Use treated sample from pH test.
2. Add R-0005 drop wise. After each drop, count, mix, and compare with color standards until desired pH is matched. See treatment tables to continue.

Base Demand Test

1. Use treated sample from pH test.
2. Add R-0006 drop wise. After each drop, count, mix, and compare with color standard until desired pH is matched. See treatment table to continue.

Total Alkalinity Test

1. Rinse and fill large comparator tube to 25 mL mark with water to be tested.*
2. Add 2 drops R-0007. Swirl to mix.
3. Add 5 drops R-0008. Swirl to mix. Sample should turn green.
4. Add R-0009 drop wise. After each drop, count and swirl to mix until color changes from green to red.
5. Multiply drops in Step 4 by 10. Record as parts per million (ppm) total alkalinity as calcium carbonate.

* When high TA is anticipated, this procedure may be used: Use 10 mL sample, 1 drop R-0007, 3 drops R-0008, and multiply drops in Step 4 by 25.

Calcium Hardness Test

1. Rinse and fill large comparator tube to 25 mL mark with water to be tested.*
2. Add 20 drops R-0010 (or use pipet provided and fill to 1 mL mark). Swirl to mix.
3. Add 5 drops R-0011L. Swirl to mix. If calcium hardness is present, sample will turn red

4. Add R-0012 drop wise. After each drop, count and swirl to mix until color changes from red to blue.
5. Multiply drops in Step 4 by 10. Record as parts per million (ppm) calcium hardness as calcium carbonate.

* When high CH is anticipated, this procedure may be used:
Use 10 mL sample, 10 drops R-0010 (or use pipet provided and fill to 0.5 mL mark), 3 drops R-0011L, and multiply drops in Step 4 by 25.

Cyanuric Acid Test

1. Rinse and fill CYA dispensing bottle (#9191) to 7 mL mark with water to be tested.
2. Add R-0013 to 14 mL mark. Cap and mix for 30 seconds.
3. Slowly transfer cloudy solution to small comparator tube until black dot on bottom just disappears when viewed from top.
4. Read tube at liquid level on back of comparator block. Record reading as parts per million (ppm) cyanuric acid.